


**NO PARTS DESCRIPTION**

1	SPOOL
2	DRAG KNOB ASSY
5	MAIN SHAFT
7	BAIL WIRE ASSY
10	ROLLER BALL BEARING
11	LINE ROLLER
12	ROLLER METAL WASHER
12A	ROLLER WASHER (TEFLON*2)
13	BAIL ARM
14	BAIL ROLLER SCREW
15	BAIL ARM SPRING SHAFT
16	BAIL ARM SPRING
17	BAIL TRIP LEVER
19	BAIL ARM SPRING GUIDE
20	ROTOR ARM COVER
22	ROTOR ASSY
22B	ROTOR RETAINED PLATE
25	MAIN HOUSING

NO PARTS DESCRIPTION

26	MAIN BODY BALL BEARING
26A	SIDE COVER BALL BEARING
27	HANDLE RETRIEVE WASHER
28	HANDLE SCREW COVER
29	A/R SHAFT
30	A/R SHAFT SPRING
30A	A/R PULLING SPRING
31	A/R SWITCH
32	A/R SWITCH SCREW
42	OSCILLATION GEAR
43A	OSCILLATION GEAR SCREW
44	SLIDE
44A	SLIDE CLIP
44D	SLIDE CLIP SCREW
45	SIDE COVER SCREW(*4)
49	HANDLE ASSY
50	MAIN SHAFT WASHER
51	MAIN SHAFT RATCHET

NO PARTS DESCRIPTION

52	SIDE COVER
53	MAIN GEAR WASHER
54	MAIN GEAR
55	PINION GEAR
56	PINION GEAR BALL BEARING
59	BALL BEARING SCREW (*3)
60	ROTOR ARM SCREW(*2)
63	ROTOR NUT
63A	HEX NUT RETAINED SCREW
64	ROTOR COVER SCREW
66	SLIDER SCREW
70	HEEL COVER BOARD SCREW
72	CLUTCH BB WASHER
73	CLUTCH BB ASSY
74	REAR COVER
75	CLUTCH BB SUPPORT
76	PINION BALL BEARING
77	CLUTCH BB COVER