


PART LIST

MAG



KEY NO	Parts Name	KEY NO	Parts Name	KEY NO	Parts Name	KEY NO	Parts Name
1	Drag knob cover	19	Dida plate fixing seat	37	screw	55	Ball beraign
2	Drag knob	20	Spring	38	Counterweight	56	Side corer
3	Spring	21	Washer	39	Square seat	57	Screw
4	Click stick	22	Main shaft	40	Wire roller	58	Body cover
5	screw	23	screw	41	Wire	59	Mainoby protective shell-A
6	Spring	24	Rotor position piece	42	Screw	60	Oscillting gear
7	Push rotor	25	Rotor	43	Plate	61	Screw
8	Position stick	26	Wire roller	44	Dust cover	62	Oscillting slider
9	Screw	27	Plastic ball bearing	45	Ball bearing	63	Screw
10	Spool stop ring	28	Position piece	46	Bearing sleeve	64	Handle nut
11	Key washer	29	Bend seat	47	One-way ball bearing	65	Mainoby protective shell-B
12	Drag washer	30	screw	48	Ball bearing	66	Spring
13	Spool	31	screw	49	Gear shaft	67	Anti-reverse lever 1
14	Line hookl	32	Stick spring	50	Body	68	Anti-reverse lever spring
15	Screw	33	Spring base	51	Aluminum feet	69	Screw
16	Dida seat	34	Bail trip shaft	52	Ball beraign	70	Anti-reverse lever 2
17	Screw	35	Wire stick	53	Drive gear	71	Handle assembly
18	Washer	36	Bend decoration	54	Drive gear washer		